

RECOMMENDED SPARE PARTS LISTS
MODEL "108" LOW-LEVEL BULK-SWEEP-OFF DEPALLETIZER
SERIAL NUMBER: 24464

Basic Machine

P106-099	4	Cam Follower
P115-091	1	Female Rod End
P44-016	2	Ball Bearing (1 1/4"B.)
P44-075	2	Bearing (3/4"B.)
P44-1147	1	Flange Bearing (2 1/2")
P44-488	2	3/4" Pillow Block Bearing
P44-766	2	Bearing (1.0"B)
P66-1242	1	E-Stop Button
P66-13155	1	Relay
P66-24311	1	Variable Frequency Drive 1hp
P66-2601	1	Limit Switch
P66-27087	2	Guard Door Switch
P66-27093	2	Proximity Sensor (18MM)
P66-43015	2	Encoder
P66-43020	2	Encoder Coupling
P66-500	1	Reflector (3" RD)
P66-7306	2	Photoeye (IO Link)
P69-4143	1	Solenoid Valve
P69-4144	1	Solenoid Valve
P69-4145	1	Solenoid Valve
P79-10101	1	Cylinder Repair Kit 4" Bore
P79-10102	1	Cylinder Repair Kit 32mm Bore
P79-125	1	Cylinder Repair Kit 1.5" Bore
P79-180	1	Cylinder Repair Kit Tier Sheet Gripper

ALWAYS SPECIFY SERIAL NUMBER OF THE MACHINE WHEN ORDERING PARTS

RECOMMENDED SPARE PARTS LISTS
MODEL "108" LOW-LEVEL BULK-SWEEP-OFF DEPALLETIZER
SERIAL NUMBER: 24464

Bottle Discharge Table

P44-058	1	Bearing (3/4" DIA.)
P44-1031	2	Bearing (3/4" DIA.)

Pallet Conveyor

P44-165	2	Bearing (1 1/4" B.)
P66-26032	2	Ultrasonic Diffuse IO Link
P69-4140	1	Solenoid Valve
P79-128	1	Cylinder Repair Kit 2.5" Bore
P79-198	1	Cylinder Repair Kit 6" Bore

Tier Sheet Remover

P44-319	1	Bearing (1" DIA.)
P69-4118	1	Solenoid Valve
P70-223	2	Vacuum Pump
P70-696	4	Vacuum Cup
P79-177	1	Cylinder Repair Kit 40mm Bore
P106-087	2	Eccentric Cam Follower
P106-059	2	Cam Follower
P79-10114	1	Triple Rod Cylinder Repair Kit

Pallet Stacker

P106-064	2	Cam Roller
P106-078	2	Cam Roller (heavy-duty)
P79-10103	1	Cylinder Repair Kit 8" Bore
P69-4139	1	Solenoid Valve

ALWAYS SPECIFY SERIAL NUMBER OF THE MACHINE WHEN ORDERING PARTS